

WARRANTY CARD

This Lee Star Appliance is fully warranted against any defect arising out of defective materials or faulty workmanship for a period of two years on motor and one years on product from the date of purchase. Should any defect develop in this product, the customer should bring the product along with this warranty card to nearest authorized service centre, where the company undertakes to get the product repaired.

Warranty is not valid if

- The use and care instructions have not been followed
- Defects are caused by accident, misuse, faulty handling, commercial use or damage in transit.
- Plastic parts are not covered under this warranty
- The repair work is carried out by persons not authorised by the company
- Any modification or alteration of any nature is made to the product
- Normal wear & tear of the product is not covered under warranty
- The bill/cash memo and copy of warranty card is not presented
- Under no circumstances, whether based on limited warranty or otherwise shall the company be liable for incidental, special or consequential damages
- Use of product indicates

REF NO.: _____

PRODUCT NAME: _____ MODEL NO.: _____

BILL NO. & DATE: _____

OWNER'S NAME & ADDRESS: _____

DEALER'S STAMP & SIGNATURE

Lee Star International

2963, Vasant Vihar, Near Industrial Estate, Ambala City-134003, Haryana (INDIA)

Helpline: +91-171-254 5555 Email: customercare@leestarindia.com

Website: www.leestarindia.com

LEE STARTM

Mixer Grinder


LE-818



Dependable and Quick Mixing!

IDENTIFY YOUR MIXER GRINDER

LE-818



SPECIFICATIONS*

Power Supply	:	220-230V AC 50Hz.
Power	:	500 Watts.
Rating	:	30 Minutes (3min. On 2 min. Off)
R.P. M.	:	12000-18000 (Approx)
No. of Jars	:	Three
Insulation	:	Class B

*Subject to change without prior notice.

HOW TO USE

ASSEMBLING THE UNIT

1. Remove all packaging materials before using.
2. Wash lid and jars in warm soapy water; rinse and dry thoroughly.
3. Clean the basic motor unit with a soft damp cloth.
4. Place the blender / grinder jar on the main unit and rotate clockwise to lock in position.

Few Tips for Blending/Mixing

1. When you blend milk shake, lassi etc. fill the blender jar upto $\frac{3}{4}$ jar capacity. This will ensure that the contents do not spill out when you start the mixer. When you want to blend the thick pastes for purees spread for sandwiches, fill the blender jar upto $\frac{1}{2}$ capacity of jar.
2. For Fruit Shakes or juices cut the fruits into small pieces, fill the cut pieces covering minimum upto the blades level and run the mixer for about a minute or so, then start adding liquid to get desired thickness.
3. Always cool hot ingredients before pouring into jar. The multi-purpose grinder jar is made of best quality stainless steel having capacity

Few Tips for Better Wet Grinding

1. While grinding fresh coconut for chutney or any other dishes for effective grinding, cut ingredients into small pieces of cubes.
2. While wet grinding, it is advise able to drain water from the ingredients, run the mixer at a low speed, then start adding required quantity of water through the large porthole on the lid to continue grinding.
3. While wet grinding tough dough, sometimes air bubbles may get trapped between the blade and paste inside, in such cases the blade will not cut any grain and will rotate freely. This will be indicated by the heavy motor sound. Stop the grinder, remove the lid, stir the ingredients thoroughly with spatula to allow the trapped air bubbles to escape. If necessary add water replace the lid and start grinding.

Few Tips for Better Dry Grinding

1. For dry grinding ensure that the ingredients are dry from moisture, shallow fried or roasted in an oven.
2. Although your mixer is designed to take tough loads always run the mixer for about three minutes and allow the motor to rest about a minute before starting again. This will help to increase the life of your motor coupler and jar bearings. Also during continuous dry grinding, the heat is generated is enormous. It may take away the flavour and nutrients of the ingredients.
3. While grinding sugar or salt never run the mixer for too long, the sugar will get melted due to over heating and stick to the blade. This will cause seizing of the job, empty the jar and pour water into the jar and run the mixer for about a minute or so to clean the melted sugar to the spindle.

Safety Precautions

- Ensure motor and jar couple are properly coupled before attempting to run the appliance.
- Remove the jar and lid only when the motor is OFF.
- Check sample of the ingredients only when the mixer is switched OFF. For sampling avoid touching the ingredients in jar instead use a spatula.
- Moving parts or blades should not be touched.
- While the appliance is in operation, do not leave it unattended.
- Keep the product and blades out of reach of children. DO not allow them to use the appliance without supervision.
- To avoid any damage to the mains cord don't let the cord hang over edges of the table or the counter or touch the hot surfaces. Ensure that the supply voltage marked on the appliance and on wall socket is the same. For safety of your appliance use only one appliance in a single wall socket.
- Always cool hot ingredients before pouring them into the blender or grinder jar.
- Handle the blades carefully. It is recommended that you should not leave blades inside the jar after use.
- Wash them under running water and do not rub them by bare hands.

Do's and Dont's

- Don't run the appliance with the jar empty prolonged running of the motor without any ingredients may wear out the jar bearings.
- Your Lee Star mixer motor is designed to work continuously for 30minutes. However, it is advisable to let the motor rest for a few minutes at least 2-3 minutes after every operation before attempting to start again.
- Do not put ice cubes in the jar. Use only crushed ice.
- Do not attempt to over load the jars more than the maximum capacity recommended in the manual.
- Do not store ingredients in the jars, empty the contents into another container on completion of the operations.
- Do not rest the appliance on any thin plastic sheet, cloth or paper while in operation. the will get sucked resulting in blockage of ventilation and excessively heat the motor.
- Do not operate the mixer grinder without the dome or lid cover in place. Do not use appliance for other than intended use.
- The appliance is for house hold use only.
- This mixer grinder is not suitable for egg whisking.